

GAME PLAY AND SCORING

HAUNTED HOUSE

BONUS MULTIPLIER

- The ball changing levels advances the "BONUS MULTIPLIER" except for when the ball is shot into the lower level up-kicker from the main playfield and when the ball rolls down the attic ramp to the main floor (middle level).
- When the ball is shot up the attic (upper level) ramp, it must first hit either a spot target or a drop target in order to advance the "BONUS MULTIPLIER".

DOUBLE SCORING

- Completing the lower level target bank twice or the upper level target bank three times lights double scoring for middle level.
- Making 11 "hits" on the upper level lights double scoring on lower level.
- Making 11 "hits" on lower level lights double scoring on upper level.
- The ball entering the attic (upper level) hole will turn off upper level light for double scoring.
- Ball entering lower level up-kicker will turn off light for lower level double scoring.

DOUBLE BONUS

- Completing the cellar (lower level) drop target bank twice lights the top left hole located on the middle playfield. The ball entering the hole lights double bonus for the attic.
- Completing the attic (upper level) drop target bank three times lights the right top hole on the main playfield. The ball entering the hole will light the double bonus for the main floor.
- Completing the target sequence 1 through 5 (in sequence) lights the center hole on the main floor (main playfield). The ball entering the hole will light the double bonus for the cellar.

EXTRA BALL

- Completing targets 1 through 5 or completing any drop target bank lights the Extra Ball lamp.
- Entering right side kicker awards Extra Ball.
- After Extra Ball is lit, any middle level switch will toggle Extra Ball light on, off, on, etc.

SPECIAL

- Completing targets 1 through 5 in order or completing upper level target bank three times lights lower level hole for Special.

- Completing lower level target bank twice lights upper level bank for Special.
- Ball entering lower level hole awards Special when lower level lamp is lit.
- Completing upper level drop target sequence awards Special when lit.

BONUS

- Bonus is random anywhere from 0-1000 points.
- Upper level hole, drop targets and spot targets will each add Bonus.
- Middle level-left outside rollover, side kicker, trap door switch, left return rollover and targets in sequence 1 through 5 will each add Bonus. When flashing, targets in sequence 1 through 5 will add 2 Bonus.
- Lower level-drop targets, spot targets and lower up-kicker will each add Bonus.

ATTIC (Upper Playfield)

HOLE

- Score 3,000 points.
- Turns off upper level double scoring light.
- Resets drop target bank (5-Ball only).

DROP TARGETS

- Score 3,000 points and adds bonus.
- Completing the sequence lights the side kicker for Extra Ball, adds an additional light to the upper level spot target sequence, resets the bank and awards Special when lit.
- Completing the sequence three times lights the cellar (lower level) hole for Special.

SPOT TARGETS

- Score 3,000 points when lit or if all targets are lit, score 3,000 points and add Bonus.
- Score 500 points unlit.

CELLAR (Lower Level)

HOLE

- Score 5,000 points.
- Awards Special when lit.

KICKING TARGET

- Score 1,000 points.

OUTSIDE ROLLOVER

- Score 1,000 points.

DROP TARGETS

- Score 3,000 points and adds Bonus.
- Completing sequence lights side kicker for Extra Ball and resets bank.
- Completing sequence twice lights attic (upper level) for Special. Left top hole on middle level and middle level for double scoring.

LEFT SPOT TARGET

- Score 1,000 points.
- Adds Bonus when lit.
- Lit after one completion of lower target bank.

RIGHT SPOT TARGET

- Score 1,000 points.
- Adds Bonus when lit.
- Lit after 2 completions of lower target bank.

LOWER UP-KICKER

- Score 3,000 points and adds Bonus if ball has fallen through the hole (up-kicker) on the main floor (middle playfield).
- Score 6,000 points if cellar (lower playfield) target bank has been completed twice and the ball has been in play on cellar (lower level) playfield.

MAIN FLOOR (Middle Playfield)

ROLL-DOWN TARGET

- Score 5,000 points.
- Lights trap door when lit.

SPOT TARGETS

- Score 500 points.

LOWER RIGHT SIDE ROLLUNDER

- Score 500 points.
- Lights left outside rollover.

LEFT OUTSIDE ROLLOVER

- Score 5,000 points.
- Adds Bonus when lit.

RIGHT OUTSIDE ROLLOVER

- Score 5,000 points.

RIGHT SIDE KICKER

- Score 500 points and adds Bonus.
- Awards Extra Ball when lit.

TRAP DOOR ROLLUNDER

- Score 500 points and adds Bonus.
- Opens trap door when lit.

TRAP DOOR SWITCH

- Score 10,000 points.
- Closes trap door.

LEFT RETURN ROLLOVER

- Score 500 points, adds Bonus and opens trap door.

THREE TOP HOLES

- Score 5,000 points.
- Lights Double Bonus when lit.

LEFT — Lights attic (upper level) Double Bonus.

CENTER — Lights cellar (lower level) Double Bonus.

RIGHT — Lights main floor (main level) Double Bonus.

TARGET SEQUENCE 1 THROUGH 5

- Score 5,000 points and add Bonus when lit.
- Score 10,000 points and add 2 Bonus when flashing.
- Score 500 points unlit.
- Completing sequence in order lights middle hole at top of main playfield, lights side kicker for Extra Ball and lights lower level hole for Special.

ADDITIONAL SCORING







- 10-point switches on all levels score 30 points.
- Pop bumpers on all levels score 1,000 points (3-Ball) or 100 points (5-Ball).







165 W. Lake Street Northlake, IL 60164
(312) 562-7400 Telex 72-8463

A Columbia Pictures Industries Company

I. INSTALLATION



LEG LEVELER



I. INSTALLATION

A. SET-UP

1. Bolt the legs to the cabinet.
2. Open the cabinet door and loosen the front moulding locking arm.
3. Remove the moulding from the playfield.
4. Slide the cabinet glass forward and remove it.
5. Raise the playboard, slide it forward and rest it on its supports.
6. From the inside of the cabinet, remove the binding strap from the power cord. Feed the cord to the outside of the cabinet through the black plastic line cord housing.
7. Place the lightbox atop the pedestal and engage the holding bracket.

LIGHTBOX HOLDING BRACKET



8. Unlock the lightbox and remove the backglass.
9. Loosen and lower the shipping bracket at the top center of the lightbox insert panel.
10. Lift the insert; then swing it out.
11. Secure the lightbox to the cabinet with the bolts and washers provided.
12. Connect all cables in the lightbox.

B. CHECK-OUT

1. Check that all cables are clear of moving parts.
2. Check for any loose wires.
3. Check switches or loose solder or other foreign matter.
4. Be certain all fuses are firmly seated.
5. Check transformers for any foreign matter across terminals.
6. Be sure transformer wiring corresponds to the supply voltage.
7. Check the setting of the normally open tilt switch on the underside of the playfield. One blade should be free-floating with a weight on the end.
8. Check that the surface of the plexiglass panel is flush with the surface of the main playfield.

CAUTION: Clean the plexiglass with glass cleaner and a soft cloth only. Never use abrasive materials.

NOTE: The allen screws used are 6-32 x 5/8" flatheads, requiring a 5/64 allen wrench.

9. Check that a sponge rubber washer has been inserted underneath the plexiglass at each attachment point.
10. Reassemble and level the game.
11. The plumb-bob tilt can be adjusted by loosening the wing nut and raising the plumb-bob to increase its sensitivity, or lowering it to decrease its sensitivity.


The ball-roll tilt can be adjusted by loosening the front screw or raising the tilt bracket to increase sensitivity, or lowering it to decrease its sensitivity.

12. With the line cord unplugged, drop a coin into one of the chutes. It should be rejected.
13. Plug the game into a properly grounded 3-wire receptacle **ONLY!**
14. Refer to **Section VI** to make all necessary game adjustments.


I. INSTALLATION

C. UPPER PLAYFIELD REMOVAL


1. Remove the two posts located at the bottom of the upper playfield ramp by unfastening the screws (one per post) which secures them to the main playfield.



4. The front left and right sides of the upper playfield are each attached to a slotted bracket with a slotted hexagon head screw. Loosen these two screws (left not shown) only enough so that the playfield can be lifted from the brackets.



2. Lift the ramp straight up and remove it from the playfield.
3. Lift the main playfield and position it so that its supports are seated on the front edge of the cabinet.




5. Lift the front end of the playfield, approximately five inches, and then pull it forward until its support brackets, located at the rear of the playfield, clear their slots.
6. The playfield's three plugs are now accessible and should now be disconnected.
7. The upper playfield can now be removed from the main playfield.


I. INSTALLATION

D. CELLAR (LOWER PLAYFIELD)

1. Remove the bolts located at the front left and right corners of the playboard. After replacing the playboard always reinstall these bolts.




2. Pull the playboard straight back until it clears the top of its front support brackets.



3. Pivot the playboard back until it rests against the upper playfield.
4. Disconnect the plugs.
5. The playfield can now be removed.


E. MIDDLE PLAYFIELD REMOVAL

1. Pivot the front end of the upper playfield until it is at least 12 inches above the front of the cabinet.



2. Pull the playfield toward you until its back end is 1 to 2 inches from the front end of the playfield support assemblies.


CAUTION: While completing step two, check that the upper playfield wiring harness, is clearing the lower playfield.



3. The upper playfield can now be pivoted back until it rests on the lightbox or, after disconnecting its wiring harness, it can be totally removed.

II. INITIALIZATION, III. GAME OPERATION

II. INITIALIZATION



III. GAME OPERATION

A. GAME START

The ball must be in the ball return trough to start a game.

1. Insert coins into coin chute.
 - a. Coin chute tune is played (dependent on Switch #27).
 - b. Total credits are displayed in status display (dependent on Switch #28).
2. Press Credit Button to start game.
 - a. Credit tune is played.
 - b. Total credits displayed decrease by one.
3. All playfield features reset.
4. The first player score display flashes a single zero.
5. When the ball is released to the shooter:
 - a. Playfield-controlled lamps flash.
 - b. High Game to Date is briefly displayed in all 4 players' score displays and the lower playfield display.

III. GAME OPERATION

B. FIRST PLAYER

1. First player's score display flashes zero.
2. The other players' displays are now blank.
3. A "1" appears on the ball-in-play display.
4. When the ball enters the outhole, any bonus earned is scored.

C. ADDITIONAL PLAYERS

1. Additional players are indicated by a zero (not flashing) in each corresponding player's display.
2. After the maximum number of players are added, or no more credits remain, the Credit Button has no effect.
3. Additional players can be added anytime the first player's ball is still in play. If the Credit Button is pressed after the first player's first ball has entered the outhole, all players' scores will be erased with the first player's score display showing a flashing zero, indicating a new game only for the first player.

D. EXTRA BALLS

1. When the SHOOT AGAIN lamp is lit, neither the player-up nor the ball-in-play display changes when the ball enters the outhole.
2. Only one extra ball per ball-in-play is given.

E. TILT MODE

1. Tilting the game results in a loss of ball in play.

2. When the game is tilted, all the playfield lamps go off.
3. All accumulated bonus and bonus multipliers are lost.

F. SLAM MODE

1. If the normally closed slam switch (located inside front door) is opened, the entire game is ended for all players.
2. The GAME OVER lamp comes on.
3. The entire switch matrix is inactive for three seconds.
4. All coins will be rejected if dropped into any coin chute during the three-second delay.
5. If the match feature exists (dependent on Switch # 18), a replay can be won even if the game is slammed.
6. Game returns to the attract mode.

G. GAME OVER

1. When the last ball enters the outhole, the GAME OVER lamp continually flashes.
2. A random number appears in the ball-in-play display. If this number matches the last two digits in any player's score, a replay (dependent on Switch # 18) is awarded.
3. HGTD is periodically flashed in all players' displays. When a score higher than this is achieved, an award (dependent on Switches #23 and #24) is given.
4. All of the target banks will reset.

IV. GAME PLAY AND SCORING

BONUS MULTIPLIER

- The ball changing levels advances the "BONUS MULTIPLIER" except for when the ball is shot into the lower level up-kicker from the main playfield and when the ball rolls down the UPPER PLAYFIELD ramp to the main floor (middle level).
- When the ball is shot up the upper level ramp, it must first hit either a spot target or a drop target in order to advance the "BONUS MULTIPLIER".

DOUBLE SCORING

- Completing the lower level target bank twice or the upper level target bank three times lights double scoring for middle level.
- Making 11 "hits" on the upper level lights double scoring on the lower level.
- Making 11 "hits" on lower level lights double scoring on upper level.
- The ball entering the upper level hole will turn off upper level light for double scoring.
- Ball entering lower level up-kicker will turn off light for lower level double scoring.

DOUBLE BONUS

- Completing the cellar (lower level) drop target bank twice lights the top left hole located on the middle playfield. The ball entering the hole lights double bonus for the upper level.
- Completing the upper level drop target bank three times lights the right top hole on the main playfield. The ball entering the hole will light the double bonus for the main floor.
- Completing the target sequence 1 through 5 (in sequence) lights the center hole on the main floor (main playfield). The ball entering the hole will light the double bonus for the cellar.

EXTRA BALL

- Completing targets 1 through 5 or completing any drop target bank lights the Extra Ball lamp.
- Entering right side kicker awards Extra Ball.
- After Extra Ball is lit, any middle level switch will toggle Extra Ball light on, off, on, etc.

SPECIAL

- Completing targets 1 through 5 in order or completing upper target bank three times lights lower hole for Special. Completing lower level target bank twice lights upper level bank for Special.
- Ball entering lower level hole awards Special when lower level lamp is lit.
- Completing upper level drop target sequence awards Special when lit.

BONUS

- Bonus is random anywhere from 0-1000 points.
- Upper level hole, drop targets and spot targets will each add bonus.
- Middle level-left outside rollover, side kicker, trap door switch, left return rollover and targets in sequence 1 through 5 will each add Bonus. When flashing, targets in sequence 1 through 5 will add 2 Bonus.
- Lower level-drop targets, spot targets and lower-level up-kicker will each add Bonus.

UPSTAIRS (Upper Playfield) HOLE

- Scores 3,000 points.
- Turns off upper level double scoring light.
- Resets drop target bank (5-Ball only).

DROP TARGETS

- Score 3,000 points and adds bonus.
- Completing the sequence lights the side kicker for Extra Ball, adds an additional light to the upper level spot target sequence, resets the bank and awards Special when lit.
- Completing the sequence three times lights the cellar (lower level) hole for Special.

SPOT TARGETS

- Score 3,000 points when lit or if all targets are lit, score 3,000 points and add Bonus.
- Score 500 points unlit.

IV. GAME PLAY AND SCORING

CELLAR (Lower Level) HOLE

- Score 5,000 points.
- Awards Special when lit.

KICKING TARGET

- Score 1,000 points.

OUTSIDE ROLLOVER

- Score 1,000 points.

DROP TARGETS

- Score 3,000 points and adds Bonus.
- Completing sequence lights side kicker for Extra Ball and resets bank.
- Completing sequence twice lights upper level for Special, left top hole on middle level and middle level for double scoring.

LEFT SPOT TARGET

- Score 1,000 points.
- Adds Bonus when lit.
- Lit after one completion of lower target bank.

RIGHT SPOT TARGET

- Score 1,000 points.
- Adds Bonus when lit.
- Lit after 2 completions of lower target bank.

LOWER UP-KICKER

- Score 3,000 points and adds Bonus if ball has fallen through the hole (up-kicker) on the main floor (middle playfield).
- Score 6,000 points if cellar (lower playfield) target bank has been completed twice and the ball has been in play on cellar (lower level) playfield.

MAIN FLOOR (Middle Playfield) ROLL-DOWN TARGET

- Score 5,000 points.
- Lights trap door when lit.

SPOT TARGETS

- Score 500 points.

LOWER RIGHT SIDE ROLLUNDER

- Score 500 points.
- Lights left outside rollover.

LEFT OUTSIDE ROLLOVER

- Score 5,000 points.
- Adds Bonus when lit.

RIGHT OUTSIDE ROLLOVER

- Score 5,000 points.

RIGHT SIDE KICKER

- Score 500 points and adds Bonus.
- Awards Extra Ball when lit.

TRAP DOOR ROLLUNDER

- Score 500 points and adds Bonus.
- Opens trap door when lit.

TRAP DOOR SWITCH

- Score 10,000 points.
- Closes trap door.

LEFT RETURN ROLLOVER

- Score 500 points, adds Bonus and opens trap door.

THREE TOP HOLES

- Score 5,000 points.
 - Lights Double Bonus when lit.
- Left - Lights upstairs (upper level) Double Bonus.
Center - Lights cellar (lower level) Double Bonus.
Right - Lights main floor (main level) Double Bonus.

TARGET SEQUENCE 1 THROUGH 5

- Score 5,000 points and add Bonus when lit.
- Score 10,000 points and add 2 Bonus when flashing.
- Score 500 points unlit.
- Completing sequence in order lights middle hole at top of main playfield, lights side kicker for Extra Ball and lights lower level hole for Special.

ADDITIONAL SCORING

- 10-point switches on all levels score 30 points.
- Pop bumpers on all levels score 1,000 points (3-Ball) or 100 points (5-Ball).

V. SOUND/SPEECH BOARD (A6), VI. GAME ADJUSTMENTS

V. SOUND/SPEECH BOARD (A6)

The Sound/SpeechBoard installed in this game has not been programmed for speech and will produce

sounds only. Please note that the voice chip (U 14) is not being used and its socket is vacant.

VI. GAME ADJUSTMENTS

A. CONTROL BOARD SWITCH ADJUSTMENTS

There are 32 switches on the control board which permit adjustment of the game parameters. These switches are contained in four packages of eight switches each, as shown below:

S1-S8 S9-S16 S17-S24 S25-S32

Switch settings are recognized only during normal power-up and when starting the first player of a new game (not when additional players are added).

SWITCHES				COIN CHUTE ADJUSTMENTS
S1	S2	S3	S4	Left Chute
S5	S6	S7	S8	Right Chute
S9	S10	S11	S12	Center Chute

NOTE: FOR GERMAN GAMES ONLY, switches S5-S8 adjust the center chute and switches S9-S12 adjust the right chute.

				COINS/CREDITS
OFF	OFF	OFF	OFF	1/1
OFF	OFF	OFF	ON	1/2
OFF	OFF	ON	OFF	1/3
OFF	OFF	ON	ON	1/4
OFF	ON	OFF	OFF	1/5
OFF	ON	OFF	ON	1/6
OFF	ON	ON	OFF	1/7
OFF	ON	ON	ON	1/8
ON	OFF	OFF	OFF	1/9
ON	OFF	OFF	ON	2/1*
ON	OFF	ON	OFF	2/2*
ON	OFF	ON	ON	2/3*
ON	ON	OFF	OFF	2/4*
ON	ON	OFF	ON	2/5*
ON	ON	ON	OFF	1/1 AND 2/3
ON	ON	ON	ON	3/1*

*NO CREDITS UNTIL LAST COIN IS INSERTED.

SWITCH 13	EXTRA CREDITS
ON	Adds 9 credits to center coin chute setting
OFF	No effect

NOTE: FOR GERMAN GAMES ONLY, Switch 13 adds 9 credits to the RIGHT coin chute setting, when ON.

SWITCH 14	COIN CHUTE CONTROL
ON	Left and Right Chutes Same
OFF	Left and Right Chutes Separate

NOTE: FOR GERMAN GAMES ONLY, Switch 14 controls the left and CENTER coin chutes.

SWITCHES	MAXIMUM CREDITS
15 16	
OFF OFF	8
OFF ON	10
ON OFF	15
ON ON	25

SWITCH 17	BALLS PER GAME
ON	3
OFF	5

SWITCH 18	MATCH FEATURE
ON	ON
OFF	OFF

SWITCH 19	REPLAY LIMIT
ON	Limits each player to one replay per game
OFF	No replay limit

SWITCH 20	NOVELTY MODE
ON	Playfield SPECIAL and EXTRA BALL features award 50,000 points and 5 knocks. High score, high game to date, and match features disabled
OFF	Normal game mode

NOTE: SWITCH 20 overrides SWITCH 21.

SWITCH 21	GAME MODE
ON	Extra Ball
OFF	Replay

NOTE: If SWITCH 21 is ON, the high game to date and match awards are disabled.

SWITCH 22	PLAYFIELD SPECIAL
ON	Awards Extra Ball
OFF	Awards Special

SWITCHES	HIGH GAME TO DATE
23 24	
OFF OFF	Not displayed-no award
OFF ON	Displayed-no award
ON OFF	Displayed-awards 2 replays
ON ON	Displayed-awards 3 replays

SWITCH 25	MUST REMAIN ON
------------------	-----------------------

SWITCH 26	MUST REMAIN ON
------------------	-----------------------

SWITCH 27	COIN SWITCH TUNE?
ON	Yes
OFF	No

SWITCH 28	CREDITS DISPLAYED?
ON	Yes
OFF	No

SWITCH 29	TILT PENALTY
ON	Ball in play only
OFF	Game over

SWITCH 30	ATTRACT FEATURES
ON	ON
OFF	OFF

SWITCH 31	MUST REMAIN OFF
------------------	------------------------

SWITCH 32	BACKGROUND TONE
ON	ON
OFF	OFF

(SEE SECTION VI, B)

VI. GAME ADJUSTMENTS

B. POST ADJUSTMENTS

None

C. SOUND ADJUSTMENTS

The speaker output is controlled by the potentiometer mounted on the fuse/knocker panel.

Turning the potentiometer counter clockwise will decrease the volume. Turning it clockwise will increase the volume.

The potentiometer is accessible through the front door.

IMPORTANT: Each of the potentiometers installed on the sound/speech board have been factory adusted. The potentiometer settings should never be changed except when performing the recommended calibration procedure.

NOTE: This game has been programmed for sound only.

SWITCH BANK (SB1) SETTINGS:


SB 1-1	USED IN SELF-TEST ONLY.	
SB 1-2	NOT USED.	
SB 1-3	SB 1-4 Attract Mode	
OFF	OFF	Disabled
ON	OFF	Every 10 Seconds.
OFF	ON	Every 2 Minutes.
ON	ON	Every 4 Minutes.
SB 1-5	ON	Background Sound enabled.
	OFF	Background Sound disabled.
SB 1-6	NOT USED.	
SB 1-7	NOT USED.	
SB 1-8	NOT USED.	

D. TRAP DOOR ADJUSTMENT

NOTE: White-lube should be used to lubricate Bracket C.

Adjust the TRAP DOOR so that it is flush to 1/64th of an inch above the surface of the PLAYFIELD by bending BRACKET A in the proper direction.

Adjust BRACKET B so that its LEADING EDGE is 1/8th to 1/4th of an inch to the left of the 45-DEGREE BEND found at the right of BRACKET C. This can be done by loosening the 2 MOUNTING SCREWS and moving BRACKET D in the appropriate direction.




VI. GAME ADJUSTMENTS

E. KICKING TARGET ADJUSTMENT

Push the PLUNGER down until it "bottoms out" in the coil HOUSING. Push the TARGET FACE in the direction of the arrow shown until it makes contact with the vertical leg of the KICKER CAM. The vertical leg of the cam is located behind the kicking target and is not shown.

Observe that the gap between the SWITCH contacts is at least $1/32$ nd of an inch. If not, bend the switch's BACKING BLADE in the proper direction.



VI. GAME ADJUSTMENTS

F. UPPER PLAYFIELD TUBE ADJUSTMENT

The tube must be adjusted so that the ball will fall freely into the tube from any direction

When necessary this adjustment can be accomplished by completing the following procedure:

1. Raise the front end of the playfield

(see section 1, upper playfield removal) high enough so that the tube clamp screw is accessible.

2. Loosen the clamp screw.
3. Adjust the tube accordingly.
4. Tighten the tube clamp screw.
5. Replace and secure the upper playfield.

G. LOWER/MIDDLE PLAYFIELD TUBE ADJUSTMENT

This tube must be adjusted so that the ball will rise freely into the tube.

The tube can be adjusted by loosening the tube bracket screws and moving the tube

bracket (located on the lower playfield) in the proper direction.

After completing the adjustment always be sure that the tube bracket screws have been retightened.



VII. BOOKKEEPING AND SELF TEST

The circuitry in this game helps the operator perform many bookkeeping and game test functions. The information is shown one step at a time in the first player's score display, while the step number is shown in the credit display (refer to flow chart Section VII, C for order and function).

- All bookkeeping information is checked against itself to insure that it is correct. If any data is invalid or bad, that information will flash while it is displayed.
- If the SELF-TEST button is not pressed within 60 seconds of each step, the game will return to the attract mode.


A. BOOKKEEPING

- Pressing the SELF-TEST button inside the front door begins the bookkeeping which are steps 01 through 15.
- The data in any of these steps may be reset to zero while it is displayed by pressing the replay button on the front door.
- THE SELF-TEST BUTTON MUST THEN BE PRESSED TO ENTER ZERO INTO MEMORY.

B. SELF-TEST


- Steps 16 through 20 are SELF-TEST or game tests the operator can use for quick troubleshooting.
- All the tests are explained in the flow chart (Section VII, D).
- Each test can be repeated by pressing the replay button on the front door. This starts the test for another 60 seconds.
- If the SELF-TEST button or the replay button is not pressed within 60 seconds, the game will return to the attract mode.

C. HOW TO RESET HIGH SCORE LEVELS OR HIGH GAME TO DATE SCORES



VII. BOOKKEEPING AND SELF TEST

D. FLOW CHART



1. If control board switch #14 is on, Steps 01 and 02 are added together and displayed in Step 01.
2. IN GERMAN GAMES ONLY, Step 02 displays total coins thru center chute, and Step 03 displays total coins thru right chute.
3. If Step 06 is reset, Steps 04 and 05 must also be reset.
4. If Step 15 is reset, Step 04 must also be reset.

NOTE A: SOLENOID ASSIGNMENTS

1. Top Hole
2. Up Kicker
5. Drop Target Bank (4)
Upper Playfield
6. Lower Playfield
8. Knocker
9. Outhole

NOTE B: Mechanical coin counters are optional and are not pulsed during solenoid test.

NOTE C: James Bond and later System 80 games will display 7641-1 for a bad 2716 game prom.

NOTE D: FOR GERMAN GAMES ONLY, solenoid #4 is assigned to center coin chute and solenoid #7 is assigned to right coin chute.

VIII. OPTIONS, IX. GENERAL INFORMATION

VIII. OPTIONS

None

IX. GENERAL INFORMATION

A. PRINTED CIRCUIT BOARDS ARE DESIGNATED AS FOLLOWS:

- A1 - Control Board
- A2 - Power Supply
- A3 - Driver Board
- A4 - Score Displays
- A5 - Status Display
- A6 - Sound/Speech Board
- A7 - Sound/Speech Power Supply
- A8 - Pop Bumper Driver Boards
- A11 - Auxiliary Lamp Driver Board - Lightbox

Printed circuit board connectors will be labeled AX-JX. For example, A3-J4 is the connector J4 on the driver board (A3).

B. WIRE COLORS ARE SHOWN AS NUMBERS:

- 0 Black
- 1 Brown
- 2 Red
- 3 Orange
- 4 Yellow
- 5 Green
- 6 Blue
- 7 Purple
- 8 Slate
- 9 White

For example, 688 is a BLUE-SLATE-SLATE striped wire.

IX. GENERAL INFORMATION

C. FUSES

FUSE PANEL

F1	Sound/Speech Power Supply 12VAC	1/2 Amp
F2	Power Supply 10VAC	5 Amp SLO-BLO
F3	Displays 60VAC	1/4 Amp SLO-BLO
F4	Solenoids 25VAC	8 Amp SLO-BLO
F5	Controlled Lamps 8VAC	7½ Amp
F6	Playboard Illumination 6.3VAC	7½ Amp SLO-BLO
F7	Light Box 6.3VAC	7½ Amp SLO-BLO
F8	Sound/Speech Power Supply 24VDC	1 Amp SLO-BLO

NOTE: F8 is not used in foreign games

MAIN PLAYFIELD

F10	Main Playfield Upper Left Pop Bumper 38VDC	2½ Amp SLO-BLO
F11	Main Playfield Bottom Left Pop Bumper 38VDC	2½ Amp SLO-BLO
F12	Upper Playfield Pop Bumper 24VDC	2 Amp SLO-BLO
F13	Lower Playfield Pop Bumper 24VDC	2 Amp SLO-BLO
F14	Main Playfield Up Kicker, Right Side Kicker and Trap Door 24VDC	2½ Amp SLO-BLO
F15	Main Playfield-Out Hole, Top Hole and Lower Playfield Hole 24VDC	2 Amp SLO-BLO

NOTE: All fuses are located on the main playfield.

IX. GENERAL INFORMATION

D. COIL CHART

SOLENOID COILS


PART NUMBER	GENERAL USAGE*	RESISTANCE (ohms)	NUMBER OF TURNS	WIRE GAUGE	WRAPPER COLOR
A-1496	KICKING TARGET KICKING RUBBERS POP BUMPERS	2.95	635	#23	Yellow
A-4893	UP KICKER POP BUMPERS BALL KICKER	2.1	535	#22	Red
A-5194	UP KICKER GONG KICKING TARGETS	4.5	780	#24	Blue
A-5195	CONTACT KICKER KNOCKER HOLE KICKER	12.3	1305	#26	White
A-16570	HOLE KICKER, OUTHOLE	15.5	1450	#27	Green
A-17875	FLIPPERS	2.8/40.0	560/1100	#24/31	Yellow
A-17891	5 BANK RESET	3.35	850	#22	White
A-18102	3 BANK RESET, 7 BANK RESET USES 2	9.0	1430	#24	Red
A-18318	4 BANK RESET	6.7	1130	#24	Orange
A-19300	BALL KICKER	7.8	1075	#25	Orange
A-20095	SUPER FLIPPER	1.55/35.5	450/900	#22/31	Red
RELAY COILS					
A-16890	Q, T, AND COIN LOCKOUT RELAYS	231.0	4000	#35	Orange
A-20558	GATE RELAY	156.0	3400	#34	White
A-18642	MEMORY/ DROP TARGETS	58.0	1590	#33	White

*Coils may vary from game to game. Check game manual for exact coil usage.

IX. GENERAL INFORMATION

E. SOUND/SPEECH BOARD (A6) TEST

1. Game must be in game over mode to initiate test.
2. Pressing the test button on the sound board will initiate the test.
3. The test must be completed to enable the sound board or game power must be turned on/off.




X. WIRING AND SCHEMATIC DIAGRAMS, PARTS LISTS

TABLE OF CONTENTS

	PAGE
CONTROL BOARD (A1)	
COMPONENT LOCATION AND PARTS LIST	20
SCHEMATIC DIAGRAM	21
DRIVER BOARD (A3)	
COMPONENT LOCATION AND PARTS LIST	24
SCHEMATIC DIAGRAM	25
SPEECH/SOUND BOARD (A6)	
COMPONENT LOCATION AND PARTS LIST	27
SCHEMATIC DIAGRAM	28
AUXILIARY LAMP DRIVER BOARD (A11)	
COMPONENT LOCATION AND PARTS LIST	30
SCHEMATIC DIAGRAM	30
LIGHT BOX WIRING	31
6-DIGIT DISPLAY (A4)	
COMPONENT LOCATION AND PARTS LIST	33
SCHEMATIC DIAGRAM	33
4-DIGIT DISPLAY (A5)	
COMPONENT LOCATION AND PARTS LIST	34
SCHEMATIC DIAGRAM	34
PLAYBOARD	
UPPER/LOWER PLAYBOARD SWITCH	
AND LAMP ASSIGNMENTS	35
MIDDLE PLAYBOARD SWITCH AND	
LAMP ASSIGNMENTS	36
PLAYBOARD SWITCH MATRIX	37
PLAYBOARD ILLUMINATION AND SOLENOIDS	38
SOUND/SPEECH BOARD POWER SUPPLY (A7)	
COMPONENT LOCATION AND PARTS LIST	40
SCHEMATIC DIAGRAM	40
BOTTOM BOARD AND CABINET SCHEMATIC	41
POWER SUPPLY (A2)	
COMPONENT LOCATION AND PARTS LIST	43
SCHEMATIC DIAGRAM	44
POP BUMPER DRIVER BOARD (A8)	
COMPONENT LOCATION AND PARTS LIST	45
SCHEMATIC DIAGRAM	45

X. WIRING AND SCHEMATIC DIAGRAMS, PARTS LISTS

CONTROL BOARD (A1) COMPONENT LOCATION




CONTROL BOARD (A1) PARTS LIST


REFERENCE	DESCRIPTION	PART NUMBER	REFERENCE	DESCRIPTION	PART NUMBER
BAT.1	Battery—3.6V	326R10-002	U3	ROM	R3272-12
C1	Capacitor, 100 mfd., 10V		U4, U5, U6	RIOT	R6532-18
C2,	Capacitor, .01 mfd., 50V		VR1	Zener Diode—3.0V, 5%	1N5225B or 1N5987B
C4-C13,			Y1	Crystal, 3.579545 MHZ	333R08-001
C15-C24,			Z1	IC-CMOS—Dual 1 Shot	SCL4528B
C26-C29,			Z2	IC—Dual Flip Flop	SN7474N
C31-C35			Z3, Z11,	IC—Hex Inverter	SN7404N
C3, C14,	Capacitor, .1 mfd., 50V		Z12, Z16,		
C25, C30			Z17, Z24,		
C36	Capacitor, 10 mfd.	10V.TNT	Z26, Z27,		
CR1-CR35	Diode, GP	1N4148	Z34, Z35		
Q1, Q4	Transistor—PNP	MPS-A70	Z4	IC-CMOS—Quad 2 Input "AND"	SCL4081B
Q2, Q3	Transistor, NPN (Motorola)	2N440	Z5	IC-Static Ram	S5101-L
R1, R6,	Resistor, 3.0K ohm, 5%, 1/4W		Z7	IC—Hex Inverter	SN74LS04N
R1 I-R24,			Z8	IC—2 Input "NOR"	SN7402N
R42, R45,			Z9, Z13,	IC—2 Input "NAND"	SN7400N
R46, R48,			Z14		
R51-R57			Z10	IC—Open Collector Inverter	SN74LS05N
R2,	Resistor, 4.7K ohm, 5%, 1/4W		Z15	IC—2 Input—"OR"	SN7432N
R34-R41			Z18, Z20	IC—"D" Flip Flop	SN74175N
R3, R43,	Resistor, 5.6K ohm, 5%, 1/4W		Z22		
R49			Z19, Z21,	IC—4 to 7 Decoder	SN7448N
R4, R5,	Resistor, 2.0K ohm, 5%, 1/4W		Z23		
R44			Z25, Z33	IC—4 to 16 Decoder	SN74154N
R7	Resistor, 62 ohm, 5%, 1/4W		Z28	IC—2-to-4 Decoder	SN74LS139N
R8, R50	Resistor, 180 ohm, 5%, 1/4W		Z29, Z30	IC—Hex Inverter—OC/HV	SN7416N
R9	Resistor, 1K ohm, 5%, 1/4W		Z31	IC—2 Input "AND"	SN7408N
R10	Resistor, 2.8M ohm, 5%, 1/4W		Z32	IC—Hex Buffer—OC	SN7417N
R25-R33	Resistor, 620 ohm, 5%, 1/4W		Z36	IC—CMOS	MM74C04 or
R47	Resistor, 24K ohm, 5%, 1/4W			Socket—DIL, 24 PIN	SCL4069B
SW1-SW4	Dip Switch Pak—8 Position	341R31-005		Spacer, Cork	640361-3
TC1	Socket, 40 Pin	640379-3			131R06-001
U1	CPU	R6502-13			
U2	ROM	R3273-12			

NOTE: UNLESS OTHERWISE INDICATED;
 1. RESISTORS ARE $\pm 5\%$, 1/4W.
 2. CAPACITORS ARE .01UF, 50V.
 3. DIODES ARE TYPE IN4148.
 4. REF. DESIGNATION Z6 NOT USED.


SPARE GATES




CLOCK LOGIC






DELAY CIRCUIT




UP/DOWN MEMORY PROTECT LOGIC




INPUT/OUTPUT DEVICE SELECTION




X. WIRING AND SCHEMATIC DIAGRAMS, PARTS LISTS






X. WIRING AND SCHEMATIC DIAGRAMS, PARTS LISTS


DRIVER BOARD (A3) COMPONENT LOCATION




DRIVER BOARD (A3) PARTS LIST


REFERENCE	DESCRIPTION	PART NUMBER
C1	Capacitor, 10 mfd., 10V— Tantalum	
C2-C19	Capacitor, .01 mfd., 50V	
CR1-CR6	Diode—Silicon	1N4148
R1-R53, R61, R55, R56, R58, R59 R54, R57, R60	Resistor, 1000 ohm, 5%, 1/4W Resistor, 9.1 ohm, 5%, 1W	
Q1-Q4, Q13-Q32, Q45-Q52, Q54-Q57, Q63 Q5-Q12, Q33-Q44 Q53, Q59, Q60 Q58, Q62, Q64	Transistor, NPN, Darlington Transistor, NPN, Darlington Transistor, NPN, Darlington Transistor, NPN	MPS-U45 MPS-A13 2N6043 2N3055
Z1-Z12 Z13	I.C. Quad "D" Latch Flip Flop I.C. Hex Inverter Insulator—Thermalloy	SN74175N SN7404N 43-03-4








- NOTE: UNLESS OTHERWISE SPECIFIED;
 1. RESISTORS ARE 1.0K, $\pm 5\%$, 1/4W.
 2. CAPACITORS ARE .01UF, 20%, 50V.
 3. DIODES ARE TYPE 1N4148.
 4. INTEGRATED CIRCUITS ARE SN74175N.
 5. TRANSISTOR TYPES MPS-A13 AND MPS-U45 ARE NPN DARLINGTONS.



D. GOTTlieb & CO.			
TITLE			
DRIVER BOARD (A3)			
SYSTEM 80			
USED ON			
DRAWN	APPROVED	DATE	
8/22/80	B.A.M.	12/12-80	E-20915

X. WIRING AND SCHEMATIC DIAGRAMS, PARTS LISTS


SOUND/SPEECH BOARD (A6) COMPONENT LOCATION




SOUND/SPEECH BOARD (A6) PARTS LIST


REFERENCE	DESCRIPTION	PART NUMBER	REFERENCE	DESCRIPTION	PART NUMBER
C1, C2	Capacitor, .1 UF 25V, CMD		R18, R21	Resistor, 100K ohm, 1/4W	
C4-C13,			R22	Resistor, 2K ohm, 1/4W, 5%	
C15, C16,			R23-R30	Resistor, 10K ohm, 1/4W	
C19, C20,			R31	Resistor, 3.3K ohm, 1/4W, 5%	
C21,			RP1, RP2	Resistor, Dip	4116R-002-222
C23, C25, C26,			SB1	Dip Switch	1008-692
C29, C30			SW1	Moment Pushbutton Switch	
C28			U1	IC, Trigger	7414
C31-C32	Capacitor, 0.05 MF, 25V, CMD		U2	IC	SN74LS74N
C42, C44			U3	CPU	R6502-13
C37	Capacitor, 4.7 MF, 25V Tantalum		U4	IC	SN74LS138N
C3, C38-C41	Capacitor, 47 MF, 50V		U5, U6	E Prom	2716
C14, C24	Capacitor, 100 PF, 250V, 20%		U7-U9, U11, U18	IC	SN74L75
C22	Capacitor, 300 PF, CMD		U10	IC	SN74LS02N
C27	Capacitor, 1 UF, 50V, TNT		U12	IC	SN7407N
C36	Capacitor, 470 MF, 35V		U13	IC, Inverter	SN74LS05N
CR1	Diode	1N4148	U14 not used	Voice Chip	SC01
CR2	Diode, Zener	1N5225B	U15	RRIOT	R6532-18
Q1, Q3	Transistor, NPN	2N2222A	U16	IC	SN74LS04N
Q2	Transistor, PNP	2N2907A	U17	IC	SN74LS30N
R1, R4, R5,	Resistor, 5.6K ohm, 1/4W		U19, U20	Converter, PMI	1408A-6P
R11, R12			U21, U22	IC	LM741CP
R2, R3	Resistor, 2K ohm, 1/4W, 5%		U23	IC	LM379S
R6, R13	Potentiometer, 10K, Bourns	3006-103	U24	IC, Dual Comparitor	LM193
R7	Resistor, 10K ohm, 1/4W, 5%		U25	Inverter	7404
R8, R8A, R14	Resistor, 1K ohm, 1/4W, 5%		Y1	Crystal, 3.579545 MHZ	
R6A, R6B	Resistor, 1.8K ohm, 5%, 1/4 watt			Socket 22 Pin Dip	640361-3
R9	2.2K ohm, 5%, 1/4W			Socket 24 Pin (2)	640379-3
R10	Resistor, 1.5K ohm, 1/4W, 5%			Socket 40 Pin (2)	
R15, R16	Potentiometer, 10K, CTS	X201R			

X. WIRING AND SCHEMATIC D






X. WIRING AND SCHEMATIC DIAGRAMS, PARTS LISTS






AUXILIARY LAMP DRIVER BOARD (A11) COMPONENT LOCATION



AUXILIARY LAMP DRIVER BOARD (A11) PARTS LIST

REFERENCE	DESCRIPTION	PART NUMBER
C1	CAPACITOR, .1 MFD, 100V	
C2-C3	CERAMIC RADIAL LEAD	
C4	CAPACITOR, .01 MFD, 100V	
Q1-Q10	TRANSISTOR, NPN	MPS-U45
R1, R12	RESISTOR, 3K OHM, 5%, 1/4 W	
R2-R11	RESISTOR, 12K OHM, 5%, 1/4 W	
R13	RESISTOR, 270K OHM, 5%, 1/4 W	
U1	I.C. 2-INPUT NAND	SN7400N
U2, U6	I.C. INVERTER	SN7405N
U3	I.C. DECADE COUNTER	SN7490N
U4	I.C. DECODER	SN7442N
U5	I.C. TIMER	LM555N
P2	10 POS. SQUARE WIRE FRICTION LOCK CONNECTOR	
P1	4 POS. SQUARE WIRE FRICTION LOCK CONNECTOR	







COLOR CODE		
0	BLACK	5 GREEN
1	BROWN	6 BLUE
2	RED	7 PURPLE
3	ORANGE	8 SLATE
4	YELLOW	9 WHITE

- NOTE:
1. NAME AND SCENE LAMPS ARE #44 OR #455 FLASHING.
 2. [XXX] INDICATES WIRE COLOR.
 3. GROUND WIRE IS 54, 18 GA.


P1
ARY
RIVER



X. WIRING AND SCHEMATIC




6-DIGIT DISPLAY (A4) COMPONENT LOCATION




6-DIGIT DISPLAY (A4) PARTS LIST

REFERENCE	DESCRIPTION	PART NUMBER
C1, C2	Capacitor, .01 mfd., 100V Kemet	C320C103MIR5CA
C3	Capacitor, 1 mfd., 100V Sprague	TE1400
DS1	6-Digit Display Tube—FUTABA	6-JS-01
R1	Resistor, 10K ohm, 5%, 1/2W	RC20GF103
Z1, Z2	IC—Fluorescent Display Driver—Sprague	UDN6118A

MATIC DIAGRAMS, PARTS LIST



4-DIGIT DISPLAY (A5) COMPONENT LOCATION



4-DIGIT DISPLAY (A5) PARTS LIST

REFERENCE	DESCRIPTION	PART NUMBER
C1	Capacitor, 1 mfd., 100V Sprague	TE1400
C2, C3	Capacitor, .01 mfd., 100V Kemet	C320C103MIR5CA
DS1	4-Digit Display Tube—FUTABA	4-LT-11
Z1	IC—Quad or Gate—T.I.	SN7432N
Z2, Z3	IC—Fluorescent Display Driver—Sprague	UDN6118A

X. WIRING AND SCHEMA

PLAYBOARD SWITCH AND LAMP ASSIGNMENTS

UPPER PLAYBOARD


SWITCH MATRIX

NO.	SWITCH ASSIGNMENT
02	#1 Drop Target
03	#1 Target
12	#2 Drop Target
13	#2 Target
22	#3 Drop Target
23	#3 Target
32	#4 Drop Target
33	#4 Target
42	10 Point
43	Pop Bumpers

LAMP

NO.	LAMP ASSIGNMENT
L21	Double Scoring
L40	#2 Target
L41	#3 Target
L42	#4 Target
L44	Special

UPSTAIRS
PLAYFIELD



LOWER
PLAYFIELD


LOWER PLAYBOARD

SWITCH MATRIX


NO.	SWITCH ASSIGNMENT
00	#1 Drop Target
01	Pop Bumper
10	#2 Drop Target
11	Kicking Target
20	#3 Drop Target
21	Outside Rollover
30	#4 Drop Target
31	Up Kicker
40	#5 Drop Target
41	Hole
50	Right Target
51	10 Point and Kicking Rubbers
60	Left Target

LAMP

NO.	LAMP ASSIGNMENT
L23	Double Scoring
L24	#1 Sequence
L25	#2 Sequence and Left Target
L26	#3 Sequence and Right Target
L45	Special




RETURNS



COLOR CODE			
0	BLACK	5	GREEN
1	BROWN	6	BLUE
2	RED	7	PURPLE
3	ORANGE	8	SLATE
4	YELLOW	9	WHITE

DRAWN APPR
 S. J. B.

PLAYFIELDS "CONTROLLED" SOLENOIDS AND ILLUMINATION



NOTE:


1. ALL DIODES ARE 1N4004.
2. LAMPS L32 THRU L43 ARE DRIVEN BY MPS-A13'S; ALL OTHER LAMPS ARE DRIVEN BY MPS-U45'S.

3. UNLESS OTHERWISE SPECIFIED; ALL LAMPS ARE #44. GROUND WIRE COLOR IS 54, 186A.
4. [XXX] INDICATES WIRE COLOR.


COILS USED			
PART NO.	DESCRIPTION	PART NO.	DESCRIPTION
A-18102	4 BANK (UPSTAIRS)	A-16570	HOLE (LOWER)
A-5195	OUTHOLE	A-20558	K RELAY (LOWER)
A-16570	TOP HOLE	A-17891	5 BANK (LOWER)
A-5194	KICKING TARGET (LOWER)	A-21741	UP KICKER (LOWER)
A-5194	UP KICKER	A-5194	KICKING TARGETS (2)
A-5195	RIGHT SIDE KICKER	A-1496	KICKING RUBBER (LOWER)
A-17875	TRAP DOOR	A-17875	FLIPPERS (8)
A-16890	U RELAY	A-1496	TOP KICKING TARGET
A-16890	GAME OVER RELAY	A-5194	KICKING RUBBER
A-16890	TILT RELAY	A-1496	POP BUMPERS (4)

COLOR CODE	
0	BLACK
1	BROWN
2	RED
3	ORANGE
4	YELLOW
5	GREEN
6	BLUE
7	PURPLE
8	SLATE
9	WHITE

PLAYFIELDS "NON-CONTROLLED" SOLENOIDS AND ILLUMINATION




X. WIRING AND SCHEMATIC DIAGRAMS, PARTS LISTS






D. GOTTLIEB & CO.			
TITLE	SOUND/SPEECH BOARD POWER SUPPLY A7		
USED ON	SYSTEM 80, GAME # 668		
DRAWN	APPROVED	DATE	D-21343
		8-5-81	


SOUND/SPEECH POWER SUPPLY (A7) COMPONENT LOCATION



SOUND/SPEECH POWER SUPPLY (A7) PARTS LIST

REFERENCE	DESCRIPTION	PART NO.
C1	Capacitor 0.1 UF	
C2	Capacitor 47 UF, 25 Volt	
C3	Capacitor 2200 UF, 50 Volt	
C4	Capacitor 0.33 UF	
CR1	Diode, Zener 30 V, ± 5%, 1W	1N4751A
CR2	Diode, Zener 12V, ± 5%, 1W	1N4742A
CR3	Diode	1N4720
CR4, CR5, CR6, CR7, CR8	Diode	1N4004
R1	Resistor 430 OHM, 5%, 1/2 Watt	
R2	Resistor 100 OHM, 1/2 Watt	
Q1	Transistor, Darlington Pair	PMD10K60
VR1	+ 12 Volt Voltage Regulator	LM 340T-12





D. GOTTLIEB & CO.

TITLE: BOTTOM BOARD AND CABINET SYSTEM 80, GAME #669

USED ON: []


DRAWN: R

APPROVED: []

DATE: 10-23-81

E-21598


DIAGRAMS, PARTS LISTS



UNLESS OTHERWISE SPECIFIED,
RESISTORS ARE $\pm 5\%$, 1/2W.
VOLTAGES ARE DC WITH RESPECT TO CIRCUIT GROUND.
VOLTAGES ARE AT NOMINAL LINE VOLTAGE (115V AC).


D. GOTTlieb & CO.				
TITLE		POWER SUPPLY (A2)		
USED ON		SYSTEM 80		
DRAWN	APPROVED	DATE	E-20922	
J.R.R.	B.A.M.	2-3-81		

X. WIRING AND SCHEMATIC DIAGRAMS, PARTS LISTS



D. GOTTLIEB & CO.			
TITLE POP BUMPER DRIVER BOARD (A8)			
SYSTEM 80			
USED ON			
DRAWN BY	APPROVED BY	DATE	
9/8/81	BAM	2-9-81	D-20923

POP BUMPER DRIVER BOARD (A8) COMPONENT LOCATION



POP BUMPER DRIVER BOARD (A8) PARTS LIST

REFERENCE	DESCRIPTION	PART NUMBER
C1, C2	Capacitor, .01 mfd., 20%, 100V	
C3	Capacitor, 4.7 mfd., 10%, 10V	
C4	Capacitor, 47 mfd., 10V	
CR1, CR2	Diode	1N4148
P1	Connector	09-65-1061
R1	Resistor, 1.5K ohm, 5%, 1/4W	
R2	Resistor, 12K ohm, 5%, 1/4W	
R3	Resistor, 220 ohm, 1/4W, 5%	
Q1	Transistor—LAMBDA	PMD10K60
Z1	IC	SN74121N
Z2	IC	SN7416N

XI. PARTS INFORMATION


TABLE OF CONTENTS

	PAGE
CABINET PART	47
MAIN PLAYBOARD PARTS	48
MAIN PLAYBOARD SWITCH MATRIX PARTS/ LAMP ASSIGNMENTS	49
MIDDLE PLAYBOARD (UNDERSIDE) COMPONENTS	50
MIDDLE PLAYBOARD ASSEMBLIES	51
UPPER PLAYBOARD PARTS / LOWER PLAYBOARD PARTS	52
UPPER PLAYBOARD SWITCH MATRIX PARTS/ LAMP ASSIGNMENTS / LOWER PLAYBOARD SWITCH MATRIX PARTS/ LAMP ASSIGNMENTS	53
UPPER PLAYBOARD ASSEMBLIES / LOWER PLAYBOARD ASSEMBLIES	54
UPPER PLAYBOARD (UNDERSIDE) COMPONENTS / LOWER PLAYBOARD (UNDERSIDE) COMPONENTS	55
LIGHTBOX PARTS	56
TRAP DOOR ASSEMBLY	57
ROLLOVER TARGET ASSEMBLY	58
VERTICAL BALL KICKER ASSEMBLY	58

XI. PARTS INFORMATION

CABINET PARTS

ITEM	DESCRIPTION	PART NO.
1.	Cabinet	Specify Game
2.	Hold Down Angle Bracket	B-19587
3.	Lightbox Mounting Bracket (4 ea.)	A-19916
4.	Playboard Support Assy. (right)	D-21539
5.	Playboard Retainer, 2 ea. (right)	B-21189
6.	Playboard Prop Channel	B-21624
7.	Knocker Assy.	MA-12
8.	Flipper Switch	B-17838
9.	Ball Shooter Assy.	B-8835
10.	Convenience Outlet	MA-17
11.	Switch	A-15401
	Switch Housing	A-15163
12.	Fuse Assy.	MA-186
13.	Front Door Assy.	Specify Game
14.	Ball Roll Tilt	MA-13
15.	Lower Playboard Retainer (left)	B-21188
16.	Diode and Terminal Strip	A-21251
17.	Upper Playfield Support Assy. (left)	D-21538
18.	Speaker	EL-80
19.	Transformer Board Assy.	
	230 Vac Transformers	B-19550
		C-19554
	German Transformers	B-19549
		C-19553
	Japanese Transformers	B-19550
	C-19554	
	Line Filter	EL-50
20.	Power Board	
	Fuse Block	EL-0
	7 Pos. Fuse Strip	EL-1
	Potentiometer, 100 ohm, 2 watt, 10%	XO-104
	F1 ½ Amp Fuse	EL-28
	F2 5 Amp Fuse Slo-Blo	EL-8
	F3 ¼ Amp Fuse Slo-Blo	EL-5
	F4 8 Amp Fuse Slo-Blo	EL-26
	F5 7½ Amp Fuse Slo-Blo	EL-22
	F6 7½ Amp Fuse	EL-22
	F7 7½ Amp Fuse	EL-22
	F8 1 Amp Fuse	EL-6
	Resistor	XO-154
	.33 ohm, 6 watt, 10%	
	Capacitor	XO-212
	100 mfd, 25V	
	Capacitor	XO-228
	6800 mfd, 25 volt	
	Capacitor	XO288
	4800 mfd, 50 volt	
	Resistor	XO-71
	1500 ohm, 2 watt, 10%	
	Bridge Rectifier	EL-42
	BR 354	
21.	Line Cord Housing	C-18534
22.	Cabinet Leg (4 ea.)	D-4337
	3" Leg Adjuster	MH-21



XI. PARTS INFORMATION


MAIN PLAYBOARD PARTS

MIDDLE PLAYFIELD

A	A-102 17	(15)
B	A-102 19	(2)
C	A-10220	(2)
D	A-102 18	(1)
E	A-10222	(2)
F	A-13 15 1	(4)
G	A-17493	(4)
H	A-15705	(1)

PARTS LIST

1. A-20271 Ball Gate Shield and A-20272 Wireform
2. A-4706 Rollunder Gate (2) and A-4705 Gate Shield (2)
3. B-19873 Arch Rod End Post and B-19874 Arch Rod End Post Cap
4. B-19875 Arch Rod Support Post (2)
5. D-19649 Arch Rod
6. C-2 1452 Metal Flat Rail
7. C-17492 Siamese Post-White (5)
8. B-2 1453 Vertical Kicker Deflector
9. A-2 1465 Upper Playfield Support Bracket
10. B-2 1593 Metal Flat Raid
11. A-2 1466 Upper Playfield Support Bracket
12. C-1 156 1 Plastic Post, 1" High, Clear (25)
13. D-2 1 140 Playboard Window, Green
14. FA-56 Allen Head Screws, 6-32 $\frac{1}{8}$ ", Flatheads (10)
FA-668 6-32 Tee Nut (10) and A-2 12 19 Rubber Washers
15. A-2 1446 Ball Guide Rail
16. A-3722 Ball Guide Rail (3)
17. B-2 1450 Metal Flat Rail
18. C-2 1253 Illuminated Post (2)
19. A-17650 Ball Guide Rail (3)
20. MA-29 Pop Bumper Coil, Bracket and Pad
21. A-2 159 1 Pop Bumper Trim Platter
22. C-10433 Pop Bumper Skirt (2) and C-10435 Body
23. A-2 1394 Pop Bumper Cap (2)
24. MA-250 Pop Bumper Coil, Bracket and Pad
25. A-2 1590 Pop Bumper Trim Platter
26. A-18070 Ball Guide Rail (2)
27. B-2 1449 Metal Flat Rail
28. A-66 12 Ball Guide Rail
29. A-2 1447 Ball Guide Rail
30. A-2 1448 Ball Guide Rail
31. A-13798 Ball Snubber Wireform (2)
32. A-17 106 Ball Guide Rail
33. D-2 1529 Plastic Set
34. A-13 150 White Jumbo Flipper (4)
35. B-202 10 Kicking Target Plastic Shield and A-2 153 1 Decal
36. B-2 14 19 Clear Tubing and B-2 142 1 Tube Bracket and Deflector
37. C-9767 Ball Shooter Gauge
38. C-2 1454 Ball Ramp
39. A-9374 Target White (4)
40. E-18793 Card Holder
41. A-14792 Mini Post Screw



XI. PARTS INFORMATION

MAIN PLAYBOARD SWITCH MATRIX PARTS/LAMP ASSIGNMENTS

MIDDLE PLAYFIELD

SWITCH MATRIX


NO. SWITCH ASSIGNMENT PART NO.

04	Left Return Rollover	B-18892
05	#3 Target	B-21561
06	#1 Trough	B-21492
14	#1 Kicking Target	B-18808
15	#4 Target	B-21561
16	#2 Trough	B-21492
24	#2 Kicking Target	B-21570
25	#5 Top Kicking Target	B-18808
26	Roll Down Target Trough	B-20978
34	Left Outside Rollover	B-19754
35	Rollunder	B-21137
36	Trap Door Trough	B-21492
44	Pop Bumper (Top)	B-19643
	Pop Bumper (Bottom)	B-19777
45	Up Kicker	B-21415
46	Top Center Hole	B-19857
54	Right Outside Rollover	B-19754
55	Right Bottom Target	B-21561
57	Tilt	B-8373
64	Roundabout	B-21569
65	Right Side Kicker	B-18079
66	10 Point (1)	B-18079
	Kicking Rubber (1)	B-18808
67	Outhole	B-18892

LAMP


NO. LAMP ASSIGNMENT

L18	Double Bonus Upstairs Playfield
L19	Double Bonus Main Playfield
L20	Double Bonus Cellar
L22	Double Scoring
L27	Top Left Hole
L28	Top Center Hole
L29	Top Right Hole
L30	#1 Kicking Target
L31	#2 Kicking Target
L32	#3 Target
L33	#4 Target
L34	#5 Kicking Target
L35	1X
L36	2X
L37	3X
L38	4X
L39	5X
L46	Left Outside Rollover
L47	Roundabout
L51	Roll Down Target



XI. PARTS INFORMATION


MIDDLE PLAYBOARD (UNDERSIDE) COMPONENTS



ITEM	DESCRIPTION	PART NO.
1.	Pop Bumper Driver Board	A-19741
2.	Transistor and Bracket	A-21618
3.	2 Resistor and Strip Assy.	A-21634
4.	9 Diode and Strip Assy.	A-21497
5.	Transistor and Bracket	A-21618
6.	Trap Door Trough Assy.	C-21479
7.	Transistor and Bracket	A-21618
8.	Fuse Block (3 ea.)	EL-0
9.	"Q" Relay	MA-224
10.	"T" Relay	MA-225
11.	"U" Relay	MA-231
12.	9 Diode and Strip Assy.	A-21497
13.	8 Diode and Strip Assy.	A-21498
14.	Pop Bumper Driver Board	A-19741
15.	Pop Bumper Driver Board	A-19741
16.	Pop Bumper Driver Board	A-19741
17.	Fuse Block	EL-0
18.	Flip Target Trough Assy.	C-21490
19.	Ball Hole Trough Assy.	E-21485
20.	Fuse Block	EL-0

XI. PARTS INFORMATION


MIDDLE PLAYBOARD ASSEMBLIES



ITEM	DESCRIPTION	ASSEMBLY PART NO.	COIL PART NO.
1.	Kicking Target Assy.	MA-205	A-1496
2.	Trap Door Assy.	MA-230	A-17875
3.	Contact Kicker	MA-176A	A-5194
4.	Contact Kicker	MA-235	A-5195
5.	Flipper Assy. Right	MA-22A	A-17875
6.	Ball Return Unit	C-21623	A-5195
7.	Flipper Assy. Right	MA-22A	A-17875
8.	Six Digit Display Assy.	MA-116	—
9.	Flipper Assy. Left	MA-22	A-17875
10.	Flipper Assy. Left	MA-22	A-17875
11.	Pop Bumper Assy.	MA-250	A-4893
12.	Kicking Target Assy.	MA-169	A-5194
13.	Kicking Target Assy.	MA-169	A-5194
14.	Pop Bumper Assy.	MA-29	A-1496
15.	Hole Kicker Assy.	MA-153A	A-16570
16.	Vertical Ball Kicker Assy.	C-21418	A-5194

XI. PARTS INFORMATION

UPPER PLAYBOARD PARTS



RUBBER RINGS


A	A-10217	(1)
B	A-10218	(1)
C	A-10219	(2)
D	A-10220	(3)
E	A-10222	(3)
F	A-13149	(1)
G	A-13151	(1)
H	A-15705	(3)

PARTS LIST

1. B-21457 Tube and Clamp
2. A-21458 Ramp Support Bracket
3. A-21589 Pop Bumper Platter
4. C-10435 Pop Bumper Body and C-10433 Skirt
5. A-21394 Pop Bumper Cap
6. A-17300 Gate Shield and A-17299 Wire Form
7. A-9347 Target - White (4)
8. A-19837 Drop Target - White (4)
9. A-18070 Ball Guide Rail (6)
10. A-17650 Ball Guide Rail (2)
11. A-6612 Ball Guide Rail
12. A-20028 Ball Guide Rail
13. C-21461 Edge Trim
14. B-21459 Edge Trim
15. B-21463 Edge Trim
16. B-21473 Edge Trim
17. C-13150 White Jumbo Flipper
18. C-11241 White Flipper
19. D-21530 Plastic Set

C-11561 Post 1" High - Clear (24)

LOWER PLAYBOARD PARTS



RUBBER RINGS

A	A-10217	(2)
B	A-10219	(1)
C	A-10220	(2)
D	A-10222	(1)
E	A-10223	(1)
F	A-13151	(2)
G	A-17493	(1)


PARTS LIST

1. C-13150 Jumbo Flipper - White
2. C-21406 Guard Rail
3. B-21410 Tube Support Bracket
4. A-13782 Ball Guide Rail
5. B-21404 Ball Guide Rail
6. A-21394 Pop Bumper Cap
7. A-10435 Pop Bumper Body and A-10433 Skirt
8. A-21592 Trim Platter
9. D-21530 Plastic Set
10. A-16038 Ball Snubber
11. C-21407-1 Ball Rail
12. D-21409-1 Ball Rail
13. A-20182 Ball Guide
14. B-21405 Ball Guide
15. A-17106 Ball Guide
16. A-17650 Ball Guide Rail
17. B-20210 Plastic Shield and A-21531 Decal
18. A-19837 Drop Target (5)
19. A-9374 Target
20. A-17492 Siamese Post
21. C-21408 Ball Rail
22. C-21226 Playboard Cover

C-11561 Post 1" High Clear (17)

XI. PARTS INFORMATION

UPPER PLAYBOARD SWITCH MATRIX PARTS/LAMP ASSIGNMENTS




SWITCH MATRIX

NO.	SWITCH ASSIGNMENT	PART NO.
02	#1 Drop Target	B-18094
03	#1 Target	B-20867
12	#2 Drop Target	B-18094
13	#2 Target	B-20867
22	#3 Drop Target	B-18095
23	#3 Target	B-20867
32	#4 Drop Target	B-18093
33	#4 Target	B-20867
42	10 Point (2)	B-18079
43	Pop Bumpers	B-19777

LAMP

NO.	LAMP ASSIGNMENT
L21	Double Scoring
L40	#2 Target
L41	#3 Target
L42	#4 Target
L44	Special

LOWER PLAYBOARD SWITCH MATRIX PARTS/LAMP ASSIGNMENTS



LOWER PLAYFIELD

SWITCH MATRIX


NO.	SWITCH ASSIGNMENT	PART NO.
00	#1 Drop Target	B-18094
01	Pop Bumper	B-19643
10	#2 Drop Target	B-18094
11	Kicking Target	B-18808
20	#3 Drop Target	B-18095
21	Outside Rollover	B-18892
30	#4 Drop Target	B-18093
31	Up Kicker	B-21415
40	#5 Drop Target	B-18093
41	Hole	B-19857
50	Right Target	B-21561
51	10 Point (Top)	B-18078
	10 Point (Bottom)	B-18079
	Kicking Rubber. (1)	B-18808
60	Left Target	B-21561

LAMP

NO.	LAMP ASSIGNMENT
L23	Double Scoring
L24	#1 Sequence
L25	#2 Sequence and Left Target
L26	#3 Sequence and Right Target
L45	Special

XI. PARTS INFORMATION

UPPER PLAYBOARD ASSEMBLIES



ITEM NO.

DESCRIPTION

1. Pop Bumper Assy.
2. Flipper Assy. (Right)
3. Flipper Assy. (Left)
4. Drop Target Assy.


ASSEMBLY PART NO.

- MA-29
- MA-22A
- MA-228
- MA-42

COIL PART NO.

- A-1496
- A-17875
- A-17875
- A-18102

LOWER PLAYBOARD ASSEMBLIES



ITEM NO.

DESCRIPTION

1. Flipper Assy. (right)
2. Pop Bumper Assy.
3. Kicking Target Assy.
4. Hole Kicker Assy.
5. Target Bank Assy.
6. Kicking Rubber Assy.
7. Flipper Assy. (left)
8. Vertical Ball Kicker Assy.

ASSEMBLY PART NO.


- MA-22A
- MA-29
- MA-169
- MA-153
- MA-43A
- MA-135
- MA-22
- C-21417

COIL PART NO.

- A-17875
- A-1496
- A-5194-
- A-16570
- A-17891
- A-1496
- A-17875
- A-21741


XI. PARTS INFORMATION

UPPER PLAYBOARD (UNDERSIDE) COMPONENTS



ITEM	DESCRIPTION	PART NO.
1.	6 Diode and Terminal Strip	A-21251


LOWER PLAYBOARD (UNDERSIDE) COMPONENTS



ITEM	DESCRIPTION	PART NO.
1.	7 Diode and Strip Assy.	A-21495
2.	6 Diode and Strip Assy.	A-21494
3.	Transistor and Bracket	A-21618
4.	"K" Gate Relay Coil Only	MA-232 A-20558

XI. PARTS INFORMATION

LIGHTBOX PARTS




ITEM	DESCRIPTION	PART NO.
1.	Cable Assy.	Specify Game
2.	Light Box Assy.	Specify Game
3.	Power Supply Assy.	MA-114
4.	Control Board Assy.	RS-30
5.	Game Prom	669/1
6.	Sound/Speech Power Supply	MA-188
7.	Master Driver Board Assy.	RS-21
8.	Sound/Speech Board Assy.	MA-216
9.	Sound Prom	669/S2
10.	Sound Prom	669/S1
11.	Grill Assy. (2 ea.)	D-20405
12.	6 Digit Display	MA-116
13.	4 Digit Display	MA-115
14.	Insert	Specify Game
15.	Back Glass	Specify Game

NOTE: Auxiliary Lamp Driver Board not shown - **Part No. MA-234.**

XI. PARTS INFORMATION


TRAP DOOR ASSEMBLY



ITEM	DESCRIPTION	PART NO.
1.	Trap Door, Bracket and Stop Assy.	A-21437
2.	Hinge Pin	A-21438
3.	Tru-Arc Retaining Ring #5133-12	FA-680
4.	Trap Door Mounting Plate	A-2384
5.	Support Bracket	A-2389
6.	Screw #6-32 x 3/16" Lg.	FA-87
7.	Spring	A-8727
8.	Tru-Arc Retaining Ring #5133-25	FA-683
9.	Tru-Arc Retaining Ring #5133-18	FA-682
10.	Link and Plunger Assy.	A-18686
11.	Spring	A-590
12.	Coil Mounting Bracket	A-15409
13.	Coil	A-17875
14.	Core	A-5065
15.	Coil Stop and Mounting	A-21441
16.	Screw	FA-67
	Washer	FA-617
17.	Lever Arm	A-21435

XI. PARTS INFORMATION


ROLLOVER TARGET



ITEM	DESCRIPTION
1.	Target Face
2.	Target Arm
3.	Fulcrum
4.	Tru-Arc Retaining Ring #5133-18
5.	Spring
6.	Shaft
7.	Nut #*-32
8.	Screw

PART NO.
See Playboard Parts Information
A-21429
A-15819
FA-682
A-21430
A-21431
FA-652
FA-300

VERTICAL UPKICKER



ITEM	DESCRIPTION	PART NO.
1.	Wire Form and Bracket	A-21414
2.	Screw - RHMS #66-32 x 3/16" Lg. (3 ea.)	FA-30
3.	Screw - RHMS #5-40 x 5/8" Lg.	FA-2
4.	Switch	B-21415
5.	Slotted Hex - WHMS #8-32 x 5/16" Lg.	FA-67
6.	Standard Washer #8	FA-617
7.	Coil Mounting Bracket	C-21416
8.	Rubber Grommet	A-5240
9.	Plunger	A-21412
10.	Spring	A-1942
11.	Coil Mounting Bracket	A-1509
12.	Diode - 1N4004	XO-254
13.	Coil	A-5194
14.	Sleeve	A-21411

Gottlieb
AMUSEMENT GAMES

165 W. Lake Street Northlake, IL 60164
(312) 562-7400 Telex 72-8463

A Columbia Pictures Industries Company 