

"RELAYS"

INDEX NO.	COIL NO.	TYPE	CONTACTS	USE
10E	A	A-9738	4B, 1C	BALL RETURN CONTROL RELAY
2E	B	A-9735	4B, 4A	POP BUMPER RELAY
4E	C	A-9735	4B, 3A	500 POINT RELAY
5E	D	A-9735	4B, 3A	3000 POINT RELAY
7E	E	A-9735	4B, 5A	BONUS SCORE RELAY
9E	F	A-469	4S, 2A,2 DISC	GO-NO UNIT RELAY
10E	G	A-9735	4B, 6A	HOLE RELAY
13E	H	A-9738	4B, 1A,1B,1C	TILT HOLD RELAY
14E	I	A-469	4S, 2A,2 DISC	10 POINT RELAY
15E	J	A-6689	4S, 1A	DOUBLE BONUS SCORE CONTROL RELAY
6E	K	A-9735	4B, 5A	1000 POINT RELAY
6E	M	A-9735	4B, 4A	100 POINT RELAY
8E	N	A-9735	4B, 5A	10 POINT RELAY
20E	O	A-9735	4B, 7A,1B	BALL RETURN RELAY
20E	P	A-9735	4B, 4A,1B	ADD PLAYER UNIT RELAY
13E	Q	A-9740	4B, 3A,2B,1C	GAME OVER RELAY
21E	R	A-9738	4B, 1A,2B,1C	HOLD RELAY
21E	S	A-9740	4B, 6A	START RELAY
13E	T	A-9742	4B, 1B	TILT RELAY
13E	U	A-9740	4B, 4A,1B,1C	1ST.BALL RELAY
9E	V	A-9740	4B, 2A	REPLAY BUTTON RELAY
21E	W	A-9740	4B, 2A,1B,1C	2ND.CREDITS RELAY
5E	X	A-9735	4B, 2A,4B	500 TARGET RELAY
14E	Z1	A-9735	4B, 8A,1B	1ST.& 2ND.PLAYER RESET RELAY
19E	Z2	A-9735	4B, 8A,1B	3RD.& 4TH.PLAYER RESET RELAY
19E	AX	A-9735	INTER	
19E	AXR	A-9742	4B,4A,2C	RESET COMPLETED RELAY
15E	BX	A-9735	INTER	4A,2B,1C LAST BALL RELAY
19E	BXR	A-9742	LOCK	
7E	EX	A-469	1A	BALL GATE RELAY
7D	KR	A-9735	4B,1B,1C	DOUBLE BONUS RELAY
19E	KXR	A-9746	LOCK	

"SEQUENCE" BANK

INDEX NO.	COIL NO.	CONTACTS	USE
3E	1B	A-1118	4A,1B,2C GREEN JOKER RELAY
3E	2B	A-1118	4A,1B,2C WHITE JOKER RELAY
3E	3B	A-1118	3A,1B,2C PURPLE JOKER RELAY
2E	4B	A-1118	6A,1B 2 JACKS RELAY
2E	5B	A-1118	6A,1B 2 KINGS RELAY
2E	6B	A-1118	5A,1B 2 QUEENS RELAY
2E	7B	A-1118	3A,1B ROYAL FLUSH RELAY
19E	8B	A-1118	2B 4TH.POS.BONUS UNIT RELAY

"OTHER COILS USED"

INDEX	COIL NO.	DESCRIPTION
1E	A-5141	FLIPPER COILS
1E	A-5194	KICKING RUBBER COILS
2E	A-4003	POP BUMPER COIL
5E	A-5195	TENS CHIME COIL
7E	A-5195	HUNDREDS CHIME COIL
8E	A-5195	THOUSANDS CHIME COIL
11E	A-5194	KNOCKER COIL
11E	A-5194	ADD REPLAY UNIT COIL
20E	A-5194	SUBTRACT REPLAY UNIT COIL
14E	A-5194	ADD PLAYER UNIT COIL
14E	A-5194	HOLE KICKER COIL
19E	A-1496	BALL RETURN COIL
19-13E	A-10259	SCORING UNIT COILS
20E	A-5194	ADD COIN UNIT COIL
20E	A-5194	RESET COIN UNIT COIL
21E	A-9736	COIN LOCKOUT COIL
22E	A-10555	TARGET BANK RESET COILS 60 HZ.
22E	A-9479	TARGET BANK RESET COILS 50 HZ.
22E	A-9479	SEQUENCE BANK RESET COIL

"WORD ABBREVIATIONS"

ADJ.= ADJUSTMENT
NO.= POSITION
POS.= POSITION

SEQ.= SEQUENCE
SUB.= SUBTRACT
TECH

"COLOR-CODE ABBREVIATIONS"

BL = BLUE	BL-L = SLATE
GR = GREEN	YEL = YELLOW
BR = BROWN	W = WHITE
BLK = BLACK	MAR = MAROON
GR = GREEN	PUR = PURPLE

EXAMPLE:
BL-WH = BLUE WITH A WHITE TRACER.
BL-WH = BLUE AND WHITE MOTTLED.

NOTE: DUE TO CIRCUMSTANCES BEYOND OUR CONTROL, IT MAY BE NECESSARY TO SUBSTITUTE WIRES OF DIFFERENT COLORS.

MOTOR SWITCH POSITIONS

POSITION	A	B	C	D	E
*1	1A,2B "S1" POS.		1A,4B "S1" POS.	2A	
*2		2B	4A,2B "S1" POS.		
*3		1A,1B		1B	
*4	1A "S1" POS.	1A,1B	3A,2B "S1" POS.		

MOTOR SEQUENCE CHART (1/3 REVOLUTION)

DEGREES	0	30	60	90	120	150	180	210	240
MOTOR 1A									
1B									
1C									
1D									
MOTOR 2B									
2C									
MOTOR 3B									
3D									
MOTOR 4A									
4B									
4C									

NOTE:
CIRCUIT IS SHOWN WITH MACHINE RESET, READY FOR 1ST.PLAYER TO SHOOT 1ST.BALL AND LINE CORD UNPLUGGED.

D. Gottlieb & Co.

COPYRIGHT © D. GOTTLIEB & CO. 1976
ALL RIGHTS RESERVED

185 W. Lake Street Northlake, Illinois 60164

#16

ROYAL FLUSH

RHH-3-11-76-333